

DRIFTAWAY

**Ready to
sleep, *anywhere?***

(How to Use)

www.ergopouch.com.au



Sound

To turn sound on and off, press and hold down the Power button for 3 seconds for track to start playing.



Change the Sound Track

To change the track, press the Sound Track Selection button once. There are seven sound tracks to choose from. The unit will return to the sound it was playing when it was last turned off.

- White Noise
- Heartbeat
- Shushing
- Fan
- Rain
- Ocean
- Nature



Light

To turn the light on, press the Power button once. The light will turn on at the lowest setting.

To increase light brightness, press the Power button again. There are three brightness settings.

To turn off the light, continue to press the Power button until the light goes out.




Volume

The unit has 25 volume settings, with the highest setting playing at 75db next to your ear, or 65db when placed 50cm/20" away. We recommend always using the unit a minimum of 2m/6.6ft away. The unit comes set at volume setting 5.



To adjust sound volume, press the volume + or volume - button until the desired volume is achieved.



Charger

The Drift Away Unit has a 48 hour playback period on a single charge. An orange light will indicate that the unit needs to be charged.

Recharge the Unit

Plug the USB-C connector into the unit's charging port.

Plug the USB-A connector into a USB-A port, or directly into an electrical outlet (wall socket) that supports a USB-A connector.

An orange light will indicate the unit is charging.

Charging time from empty to full is two hours. The orange light will turn off once fully charged.

Once charged, remove the USB-C cable to use and transport the unit.

The unit's charging voltage is DC 5V/0.5A. The unit is safe to be used when plugged in.

For Baby

Place the unit on a flat surface, at least 2m/6.6ft away from your baby when in use. Never place the unit next to your baby's ears such as in the bassinet, cot/crib, or pram.

Use the unit to assist settling your baby to sleep. Once baby is asleep, turn off the unit.

High volume sounds can be intrusive during sleep, and can have the opposite intended effect. We recommend using the unit only as a background sound, never in the foreground, and with the volume used at a low setting.

We recommend that the unit is used as a sleep settling tool for newborn babies up to 12 months old. To avoid white noise becoming a sleep crutch, try not to use the unit for every sleep.

Prior to use, please ensure to read our Safety, Care and Maintenance manual including manufacturer's directions and safety warnings.

For Adults

Place the unit on a flat surface, at least 2m/6.6ft away from your head when in use.

High volume sounds can be intrusive during sleep, and can have the opposite intended effect. We recommend using the unit only as a background sound, never in the foreground, and with the volume used at a low setting.

Prior to use, please ensure to read our Safety, Care and Maintenance manual including manufacturer's directions and safety warnings.